

Door Lock Clamp Adjustment



After installing new hinges, it would be necessary to proceed adjusting the door lock clamp. Over ages hinges wear and doors are gradually sagging, resulting in difficult and improper door closing. It may be possible to have adjusted the door lock clamp somewhere in the past in order to make your door function better, but now since the hinges are new, you should adjust the lock clamp from scratch.

You must undo the three adjustment screws in order to free up the clamp. You may now move the clamp to all directions; up - down - left - right.

Tighten up the screws when you have obtained perfect closing of the door. This procedure may be time consuming since every mm of adjustment affects the proper closing of the door latch mechanism and of course door closing.